

•Step 1

Remove Heat transfer paste from packaging



•Step 2

Apply Heat transfer paste to the condenser



- **Step 3**

Ensure that the heat transfer paste is spread evenly



- **Step 4**

Dilute dishwashing liquid (soapy concentrate) and apply to the edge of the glass to ensure easy insertion coat an area of about 35mm all around the tube.



- **Step 5**

Remove the plastic cup like holder by turning it anti clockwise



- **Step 6**

Insert the tube through the holder make sure that there is at least a hand space between the lip of the tube and the manifold.



- **Step 7**

Use the hand space to insert the condenser into the manifold



- **Step 8**

Ensure that the condenser is inserted all the way into the manifold.



- **Step 9**

Insert the glass tube, this should slide in easily if enough soapy water was used, if not try adding more soap.



- **Step 10**

Replace the cup like holders, turning it clockwise to tighten, **DO NOT OVER TIGHTEN!**

